

## Environmental Protection Agency

## § 63.7300

oven battery, you must meet each of the requirements in paragraphs (b)(1) through (4) of this section.

(1) You must equip each quench tower with baffles such that no more than 5 percent of the cross sectional area of the tower may be uncovered or open to the sky.

(2) You must wash the baffles in each quench tower once each day that the tower is used to quench coke, except as specified in paragraphs (b)(2)(i) and (ii) of this section.

(i) You are not required to wash the baffles in a quench tower if the highest measured ambient temperature remains less than 30 degrees Fahrenheit throughout that day (24-hour period). If the measured ambient temperature rises to 30 degrees Fahrenheit or more during the day, you must resume daily washing according to the schedule in your operation and maintenance plan.

(ii) You must continuously record the ambient temperature on days that the baffles were not washed.

(3) You must inspect each quench tower monthly for damaged or missing baffles and blockage.

(4) You must initiate repair or replacement of damaged or missing baffles within 30 days and complete as soon as practicable.

(c) As provided in § 63.6(g), you may request to use an alternative to the work practice standards in paragraph (b) of this section.

### **§ 63.7296 What emission limitations must I meet for battery stacks?**

You must not discharge to the atmosphere any emissions from any battery stack at a new or existing by-product coke oven battery that exhibit an opacity greater than the applicable limit in paragraphs (a) and (b) of this section.

(a) Daily average of 15 percent opacity for a battery on a normal coking cycle.

(b) Daily average of 20 percent opacity for a battery on batterywide extended coking.

## OPERATION AND MAINTENANCE REQUIREMENTS

### **§ 63.7300 What are my operation and maintenance requirements?**

(a) As required by § 63.6(e)(1)(i), you must always operate and maintain your affected source, including air pollution control and monitoring equipment, in a manner consistent with good air pollution control practices for minimizing emissions at least to the levels required by this subpart.

(b) You must prepare and operate at all times according to a written operation and maintenance plan for the general operation and maintenance of new or existing by-product coke oven batteries. Each plan must address, at a minimum, the elements listed in paragraphs (b)(1) through (6) of this section.

(1) Frequency and method of recording underfiring gas parameters.

(2) Frequency and method of recording battery operating temperature, including measurement of individual flue and cross-wall temperatures.

(3) Procedures to prevent pushing an oven before it is fully coked.

(4) Procedures to prevent overcharging and undercharging of ovens, including measurement of coal moisture, coal bulk density, and procedures for determining volume of coal charged.

(5) Frequency and procedures for inspecting flues, burners, and nozzles.

(6) Schedule and procedures for the daily washing of baffles.

(c) You must prepare and operate at all times according to a written operation and maintenance plan for each capture system and control device applied to pushing emissions from a new or existing coke oven battery. Each plan must address at a minimum the elements in paragraphs (c)(1) through (3) of this section.

(1) Monthly inspections of the equipment that are important to the performance of the total capture system (*e.g.*, pressure sensors, dampers, and damper switches). This inspection must include observations of the physical appearance of the equipment (*e.g.*, presence of holes in ductwork or hoods, flow constrictions caused by dents or accumulated dust in ductwork, and fan